

Engineering Data Sheet

Document No:- 004B01000D799 rev 2

Installation, Operation & Maintenance Instructions for
Fig 1000 Copper Alloy Metering Stations

Page 1 of 4
Date 14th December 2004

CE MARKING AND THE PRESSURE EQUIPMENT DIRECTIVE 97/23/EC

This has been implemented in United Kingdom law by the Pressure Equipment Regulations 1999 (SI 1999/2001).

The regulations apply to all piping products with a maximum allowable pressure greater than 0.5 bar. Products with a maximum allowable pressure not exceeding 0.5 bar are outside the scope of the Directive. Products are categorised in accordance with the maximum working pressure, size and ascending level of hazard, which is dependent on the fluid being transported. Fluids are classified as Group 1, dangerous fluids or Group 2, all other fluids including steam. Categories are SEP (sound engineering practice) and for ascending levels of hazard, I, II, III or IV. All valves designated as SEP do not bear the CE mark nor require a Declaration of Conformity. Categories I, II, III or IV carry the CE mark and require a Declaration of Conformity (Note- all products up to and including 25mm (1") having a maximum allowable pressure greater than 0.5 bar are designated SEP regardless of fluid group.)

PRODUCT LIFE CYCLE

The life of the metering station is dependent on its application, frequency of use and freedom from misuse. Compatibility with the system into which it is installed must be considered. The properties of the fluid being transported such as pressure, temperature and the nature of the fluid must be taken into account to minimise or avoid premature failure or non-operability. A well-designed system will take into consideration all the factors considered in the metering station design, but additionally electrolytic interaction between dissimilar metals in the metering station and the system must be examined. Before commissioning a system, it should be flushed to eliminate debris and chemically cleaned as appropriate to eliminate contamination, all of which will prolong the life of the metering station.

LIMITS OF USE

The metering station to which these installation, operation and maintenance instructions apply have been categorised in accordance with the Pressure Equipment Directive.

The fluid to be transported is limited to Group 2 liquids i.e. non-hazardous and on no account must these valves be used on any Group 2 gases, Group 1 liquids or Group 1 Gases.

Fig 1000 dezincification resistant copper alloy metering stations in PN16 and PN20 pressure ratings and in sizes up to and including 2 inch are categorised as SEP and do not require the CE mark

Operating pressures and temperatures

Fig No	PN	Non-shock pressure at temperature range	Non-shock pressure at max. temperature
1000C 1000	16 Compression 20 Threaded	16 bar from 2°C to 30°C 20 bar from -10°C to 90°C	5 bar at 120°C 15 bar at 120°C

Not suitable for fatigue loading, creep conditions, fire testing, fire hazard environment, corrosive or erosive service, transporting fluids with abrasive solids.

The Fig. 1000 complies with BS7350. It must be installed into a piping system where the normal pressure does not exceed the above rating. The Figure 1000 is fitted as standard with Hattersley Figure 631 test points and optionally fitted with Hattersley Figure 750 valve isolating test points, (Figure 1000HT). The temperature is restricted for the Figure 631 to 120°C and for the Figure 750 to 180°C due to their elastomeric seals.

Engineering Data Sheet

Document No:- 004B01000D799 rev 2

Installation, Operation & Maintenance Instructions for
Fig 1000 Copper Alloy Metering Stations

Page 2 of 4
Date 14th December 2004

The maximum allowable pressure in metering stations as specified in the standards is for non-shock conditions. Water hammer and impact for example, should be avoided.

If the limits of use specified in these instructions are exceeded or if the metering station is used on applications for which it was not designed, a potential hazard could result.

LAYOUT AND SITING

It should be considered at the design stage where metering stations will be located to give access for operation, adjustment, maintenance and repair.

Piping must be provided with adequate support to avoid the imposition of pipeline strains on the metering station, which would impair its performance.

INSTALLATION

The Fig. 1000 metering station should be installed with a minimum of 5 diameters of straight pipe upstream having the same nominal diameter as the metering station and should not include any reducers or any other intrusions into the bore within this specified length.

The Fig. 1000 may be installed close coupled to a Hattersley gate valve, ball valve or double regulating globe valve.

When the Fig. 1000 is used in isolation, a minimum of 3 diameters of straight pipe must be fitted downstream.

Prior to installation, a check of the body marking must be made to ensure that the correct metering station is being installed.

Metering stations are precision manufactured items and as such, should not be subjected to misuse such as careless handling, allowing dirt to enter the metering station through the end ports, lack of cleaning both metering station and system before operation.

All special packaging material must be removed.

Piping must be provided with adequate support to avoid the imposition of pipeline strains on the metering station, which would impair its performance.

Immediately prior to valve installation, the pipework to which the metering station is to be fastened should be checked for cleanliness and freedom from debris.

Confirm that the pipe threading length is correct to avoid excessive penetration of the pipe into the metering station, which may otherwise cause damage.

Thread sealing compounds appropriate to the application must be used but excessive use should be avoided, since this increases thread interference and may cause overstressing of the body ends. Excessive sealant may be extruded into the metering station bore effecting the signal readings and flow measurement accuracy.

It is important that the internal pipe bore at the point upstream to the metering station is free from internal burrs, weld spatter or other defects which will disrupt the velocity profile of the liquid and induce inaccuracies outside the flowrate accuracy specified.

Engineering Data Sheet

Document No:- 004B01000D799 rev 2

Installation, Operation & Maintenance Instructions for
Fig 1000 Copper Alloy Metering Stations

Page 3 of 4
Date 14th December 2004

It is important to ensure that the flow arrow on the metering station is coincident with the direction of flow in the pipeline. If close coupled to a valve the metering station must be upstream, that is the flow passing through the metering station before the valve.

Conventionally, metering stations are installed in horizontal pipelines but it is acceptable to install in any attitude.

It is preferable to have the plane of the test points above horizontal to prevent the accumulation of debris.

Recommended attitudes for the test points are:

In horizontal pipework at low level

With the upstream (HP) test point pointing vertically upwards. This will prevent the other (LP) test point from acting as a dirt pocket, since the latter will be horizontal and half way from the bottom of the pipe. Also the (HP) test point can be used to bleed air from the system.

Where pipework runs close to a wall or there is some other obstruction, it is essential that there is a 100mm clearance to allow a manometer probe to be connected to the test point.

This may mean that one test point (HP or LP) has to point up at 45 degrees which will still limit the extent to which its opposite serves as a dirt pocket, i.e. keep test points away from the bottom of the pipe.

In horizontal pipework at high level

As for low level. Where pipework is enclosed in ceilings or voids it may be difficult to reach across other pipework, cable trays etc. in order to connect the manometer probes to the test points on the topside of the pipe.

Where this difficulty is likely to occur, it may be advantageous to have both test points pointing down at 45 degrees. This will ensure that neither is located as an obvious dirt pocket.

In vertical pipework

For vertical pipework, there are no obvious dirt entrapment areas and therefore the orientation of the test points is fully dependent upon the ease of manometer probe connection.

OPERATING

The only operation required is during the commissioning stage. During this stage all entrained air must be expelled from the system before accurate measurements of differential pressure signals can be taken from the test points.

Each test point is fitted with a captive cap retained by a coloured strap:

Upstream (HP) - Red
Downstream (LP) - Blue

Note: For safety reasons all probe insertions during commissioning must be carried out with the system cold.

For the Figure 631, these measurements are taken by directly inserting the test probe into the test point, a silicone oil or grease should be lightly smeared onto the test probe prior to insertion.

Engineering Data Sheet

Document No:- 004B01000D799 rev 2

Installation, Operation & Maintenance Instructions for
Fig 1000 Copper Alloy Metering Stations

Page 4 of 4
Date 14th December 2004

For the Figure 750, these measurements are taken by opening the isolation valve on the test point using an air vent key (Hattersley Fig. 426) after manometer probe connection.

MAINTENANCE

The Figure 1000 metering stations are maintenance free.

The valve should be at zero pressure and ambient temperature prior to any inspection.

Maintenance Engineers & Operators are reminded to use correct fitting tools and equipment.
A full risk assessment and methodology statement must be compiled prior to any maintenance.

The risk assessment must take into account the possibility of the limits of use being exceeded whereby a potential hazard could result.

A maintenance programme should therefore include checks on the development of unforeseen conditions, which could lead to failure.

For the supply of genuine Hattersley spares, technical assistance or Hattersley ValveServe contact:

Hattersley Newman Hender
Peel House, Peel Road, West Pimbo, Skelmersdale, Lancashire. WN8 9PT

Telephone : 01695 712800
Facsimile : 01695 712820
Email : uksales@hattersley.com
: export@hattersley.com

Service Freephone : 0500 618205